

**QUALIDYNE SYSTEMS, INC.**  
**Case 02/03/04 Power Supply**  
**Installation Manual**

**CERTIFICATION**

Qualidyne Systems, Inc. certifies that this product meets the published specification at the time of shipment from the factory.

**WARRANTY**

This Qualidyne power supply is warranted against defects in material and workmanship for a period of one year from date of shipment. During this period Qualidyne will either repair or replace this product if proven to be defective.

**MODEL NUMBERS**

This manual applies to power supply models 02XYZ, 03XYZ and 04XYZ for AC input units. Manual part no. 200024 fourth printing, October 1990.

**INSTALLATION MANUAL**

This manual explains how to install the equipment and how to do some basic troubleshooting.

**SAFETY SYMBOLS**



This symbol indicates dangerous voltages present within the power supply. Isolation transformers should be used between the AC mains and the power supply if work is to be carried out with the Safety covers removed.

**GENERAL SAFETY**

The Case 02, 03, 04 power supply series is primarily designed to be used with other equipment or enclosures, which restricts access to authorized personnel only.

Make sure that the unit is being supplied by a power source as indicated on the label.

Slots in the case are designed for ventilation and must not be obstructed when the product is installed and/or operated.